

Marine Turbine Series





The Turbine Series Electric Primer
Pump Kits can be retrofitted to many of
the Racor 900 or 1000 series fuel filters
already in service. The Filter Pump is
an innovative and proprietary system
consisting of a pre-screen filter, a flow
bypass circuit and a roller cell pump
powered by a DC motor. When the switch
is activated the fuel is drawn into the
pre-screen and then pumped through the
housing, refilling the unit with fuel. When
not in use the Filter Pump system is
bypassed and the Racor fuel filter/water
separator functions normally.

The RKP1912, 12V DC Kit, contains a traditional brushed motor design. The RKP1924, 24V DC Kit, contains innovative brushless motor technology. The use of this primer pump kit allows the operator to easily re-prime the Racor Filter/Separator directly from the fuel storage tank with no mess

Marine Turbine Series filter assemblies are designed to be installed on the vacuum side of the fuel transfer pump for best efficiency and protect precision engine components from dirt, rust, algae, asphaltines, varnishes, and especially water, which is prevalent in engine fuels. They remove contaminates from fuel using the following legendary three stage process:

Stage One: Separation

As fuel enters the filter assembly, it moves through the centrifuge and spins off large solids and water droplets which fall to the bottom of the collection bowl.



And more...

Stage Two: Coalescing

Small water droplets bead-up on the surface of the conical baffle and cartridge element. When heavy enough, they too fall to the bottom of the bowl.

Stage Three: Filtration

Proprietary Aquabloc II cartridge elements repel water and remove contaminants from fuel down to 2 micron (nominal). They are waterproof and effective longer then water absorbing elements.



500 Series Overview

Applies to all models.



















Specifications	500MA ¹	500MAM	503MA	75500MAX	75500MAXM
Maximum Flow Rate One Filter On-line Two Filters On-line	60 GPH (227 LPH) N/A	60 GPH (227 LPH) N/A	60 GPH (227 LPH) N/A	60 GPH (227 LPH) 120 GPH (454 LPH)	60 GPH (227 LPH) 120 GPH (454 LPH)
Application	Diesel	Gasoline or Diesel	Diesel	Diesel	Gasoline or Diesel
Port Size	3/4"-16 (SAE J1926)	3/4"-16 (SAE J1926)	3/8" NPTF	3/4"-16 (SAE J1926)	3/4"-16 (SAE J1926)
Height	11.5 in. (29.2 cm)	11.0 in. (27.9 cm)	11.5 in. (29.2 cm)	11.5 in. (29.2 cm)	11.0 in. (27.9 cm)
Width	5.8 in. (14.7 cm)	5.8 in. (14.7 cm)	5.8 in. (14.7 cm)	14.5 in. (36.8 cm)	14.5 in. (36.8 cm)
Depth	4.8 in. (12.2 cm)	4.8 in. (12.2 cm)	4.8 in. (12.2 cm)	9.5 in. (24.1 cm)	9.5 in. (24.1 cm)
Weight	4.0 lb (1.7 kg)	5.0 lb (2.2 kg)	4.0 lb (1.7 kg)	17 lb (7.7 kg)	18 lb (8.2 kg)
Clean Pressure Drop	0.3 PSI (1.7 kPa)	0.3 PSI (1.7 kPa)	0.3 PSI (1.7 kPa)	0.7 PSI (4.8 kPa)	0.7 PSI (4.8 kPa)
Maximum Pressure	25 PSI (1.0 bar)	25 PSI (1.0 bar)	25 PSI (1.0 bar)	25 PSI (1.0 bar)	25 PSI (1.0 bar)
Water Capacity	3.7 oz (110 ml)	3.7 oz (110 ml)	3.7 oz (110 ml)	7.4 oz (220 ml)	7.4 oz (220 ml)
Overhead Clearance	4.0 in. (10.2 cm)	4.0 in. (10.2 cm)	4.0 in. (10.2 cm)	4.0 in. (10.2 cm)	4.0 in. (10.2 cm)
Water Removal Efficiency	99%	99%	99%	99%	99%
Ambient Fuel Temperature	-40° to +250°F² (-40° to +121°C)				
Max. Fuel Temperature	190°F (32°C)				

¹ Add * for optional 16MM ports. Example (*500MA30). ² With maximum fuel temperature 190°F (32°C).





900 Series Overview

Applies to all models.



















Specifications	900MA	900MAM	903MA //	7,5900MAX	75900MAXM
Maximum Flow Rate:One Filter On-line	90 GPH (341 LPH) N/A	90 GPH (341 LPH) N/A	90 GPH (341 LPH)	90 GPH (341 LPH)	90 GPH (341 LPH) 180 GPH (681
Two Filter On-line				LPH)	LPH)
Application	Diesel	Gasoline or Diesel	Diesel	Diesel	Gasoline or Diesel
Port Size	7/8"-14 (SAE J1926)	7/8"-14 (SAE J1926)	1/2"-14 NPT	7/8"-14 (SAE J514)	7/8"-14 (SAE J514)
Height	17.0 in. (43.2 cm)	16.5 in. (41.9 cm)	17.0 in. (43.2 cm)	17.0 in. (43.2 cm)	16.5 in. (41.9 cm)
Width	6.0 in. (15.2 cm)	6.0 in. (15.2 cm)	6.0 in. (15.2 cm)	18.8 in. (47.6 cm)	18.8 in. (47.6 cm)
Depth	7.0 in. (17.8 cm)	7.0 in. (17.8 cm)	7.0 in. (17.8 cm)	11.0 in. (27.9 cm)	11.0 in. (27.9 cm)
Weight	6.0 lb (2.7 kg)	7.0 lb (3.2 kg)	6.0 lb (2.7 kg)	23 lb (10.4 kg)	24 lb (10.9 kg)
Clean Pressure Drop	0.34 PSI (2.4 kPa)	0.34 PSI (2.4 kPa)	0.34 PSI (2.4 kPa)	1.7 PSI (11.7 kPa)	1.7 PSI (11.7 kPa)
Maximum Pressure	25 PSI (1.0 bar)	25 PSI (1.0 bar)	25 PSI (1.0 bar)	25 PSI (1.0 bar)	25 PSI (1.0 bar)
Water Capacity	10.3 oz (305 ml)	10.3 oz (305 ml)	10.3 oz (305 ml)	20.6 oz (610 ml)	20.6 oz (610 ml)
Overhead Clearance	5.0 in. (12.7 cm)	5.0/in. (12.7 cm)	5.0 in. (12.7 cm)	5.0 in. (12.7 cm)	5.0 in. (12.7 cm)
Water Removal Efficiency	99%	99%	99%	99%	99%
Ambient Fuel Temperature	-40° to +250°F¹ (-40° to +121°C)				
Max. Fuel Temperature	190°F (32°C)				

¹ With maximum fuel temperature 190°F (32°C).



1000 Series Overview

Applies to all models.



















Specifications	1000MA	1000MAM	1003MA	₹\$1000MA	731000MAM
M			5////		
aximum Flow Rate:			$/\Lambda V////$		
One Filter On-line	180 GPH (681 LPH)	,	180 GPH (681/LPH)	// N/A	N/A
Two Filters On-line	N/A	N/A	N/A	360 GPH (1363 LPH)	,
Application	Diesel	Gasoline or Diesel	Diesel	Diesel	Gasoline or Diesel
Port Size	7/8"-14 (SAE J1926)	7/8"-14 (SAE J1926)	1/2"214 NPT	3/4"-14 (SAE J476)	3/4"-14 (SAE J476)
Height	22.0 in. (55.9 cm)	21.5 in. (54.5 cm)	22.0 in. (55.9 cm)	22.0 in. (55.9 cm)	21.5 in. (54.5 cm)
Width	6.0 in. (15.2 cm)	6.0 in. (15.2 cm)	6.0 in. (15.2 cm)	16.5 in. (41.9 cm)	16.5 in. (41.9 cm)
Depth	7.0 in. (17.8 cm)	7.0 in. (17.8 cm)	7.0 in. (17.8 cm)	12.0 in. (30.5 cm)	12.0 in. (30.5 cm)
Weight	10 lb (4.5 kg)	11 ib (5.0 kg)	10 lb (4.5 kg)	26 lb (11.8 kg)	27 lb (12.2 kg)
Clean Pressure Drop	0.5 PSI (3.4 kPa)	0.5 PSI (3.4 kPa)	0.5 PSI (3.4 kPa)	1.7 PSI (11.7kPa)	1.7 PSI (11.7 kPa)
Maximum Pressure	25 PSI (1.0 bar)	25 PSI (1.0 bar)	25 PSI (1.0 bar)	25 PSI (1.0 bar)	25 PSI (1.0 bar)
Water Capacity	10.3 oz (305 ml)	10.3 oz (305 ml)	10.3 oz (305 ml)	20.6 oz (610 ml)	20.6 oz (610 ml)
Overhead Clearance	10.0 in. (25.4 cm)	10.0 in. (25.4 cm)	10.0 in. (25.4 cm)	10.0 in. (25.4 cm)	10.0 in. (25.4 cm)
Water Removal	99%	99%	99%	99%	99%
Efficiency	° to +250°F (-40° to +121°C)				
Ambient Fuel		-40			
Mampenel ure	190oF (32oC)				
Temperature			1000. (0200)		



1000 Series Overview

Applies to all models.

















Specifications	751000MAX	751000MAXM	// 7/1000MA	791000MAV
Maximum Flow Rate:One Filter On- line Two Filters On-line Three Filters On-line	180 GPH (681 LPH) 360 GPH (1363 LPH) N/A	180 GPH (681 LPH) 360 GPH (1363 LPH) N/A	N/A N/A 540 GPH (2044 LPH)	180 GPH (681 LPH) 360 GPH (1363 LPH 540 GPH (2044 LPH)
Application	Diesel	Gasoline or Diesel	Diesel	Diesel
Port Size	7/8"-14 (SAE J514)	7/8"-14 (SAE J5/4)	1"-11.5 (SAE J476)	3/4"-14 (SAE J476)
Height	22.0 in. (55.9 cm)	21.5 in. (54.6 cm)	22.0 in. (55.9 cm)	22.0 in. (55.9 cm)
Width	18.8 in. (47.6 cm)	18.8 in. (47.6 cm)	21.5 in. (54.6 cm)	21.5 in. (54.6 cm)
Depth	11.0 in. (27.9 cm)	11.0 in. (27.9 cm)	12.0 in. (30.5 cm)	11.8 in. (30.0 cm)
Weight	30 lb (13.6 kg)	31 lb (14.1 kg)	39 lb (17.7 kg)	52 lb (23.6 kg)
Clean Pressure Drop	3.7 PSI (25.5 kPa)	3.7 PSI (25.5 kPa)	1.7 PSI (11.7 kPa)	2.5 PSI (17.2 kPa)
Maximum Pressure	25 PSI (1.0 bar)	25 PSI (1,0 bar)	25 PSI (1.0 bar)	25 PSI (1.0 bar)
Bowl Capacity	20.6 oz (610 ml)	20.6 oz (610 ml)	30.9 oz (915 ml)	30.9 oz (915 ml)
Overhead Clearance	10.0 in. (25.4 cm)	10.0 in. (25.4 cm)	10.0 in. (25.4 cm)	10.0 in. (25.4 cm)
Water Removal Efficiency	99%	99%	99%	99%
Ambient Fuel Temperature	-40° to +250°F¹ (-40° to +121°C)			
Max. Fuel Temperature	190oF (32oC)			



How to Order

(The example below illustrates how the part numbers are constructed).

900MA	М	10
Basic Model Number Use model 903MA for 22x1.5 mm metric thread	Add M for metal bowl.	Specify: 2 (for 2 micron) 10 (for 10 micron) 30 (for 30 micron)


Replacement Element (seals included)				
2040SM-OR 2 micron Final				
2040TM-OR	10 micron	Secondary		
2040PM-OR	30 micron	Primary ¹		

¹ A secondary or final filter is required downstream.

All 2040 Series filters are 4.6" tall by 4.7" in diameter.

Not all configurations are available - contact Technical Support for more information.

Mounting Information





Replacement Parts

900MA and 903MA

Part Number **Description**

RK 11888 1. T-handle Kit (includes o-ring)

RK 11-1933-04 Lid Kit (includes #3)

3. 11007 Lid O-ring

4. Replacement Element (includes #3)

> 2040SM-OR 2 Micron Element 2040TM-OR 10 Micron Element 2040PM-OR 30 Micron Element

RK 11815-102 Body Clamp Bracket Kit 5.

6. RK 19002-02 Outer Cylinder Kit

(includes #9)

7. **RK 11028B** Checkball and Seal Kit 8. **RK 11026D** Turbine/Centrifuge Kit

11007 **Bowl O-ring**

10. RK 11-1606-1 Clear Bowl Kit (includes # 9)

RK 11734 Metal Bowl Kit

Metal Bowl Kit (1/4"NPT) RK 11734-01

11. RK 11037A Bowl Ring Kit

Capscrew Kit (1/4"-20 x 1") 12. RK 11542

(includes 4 capscrews)

13. **RK 11341** Bowl Drain Gasket Kit 11041 Bowl Drain Washer

Heat Deflector Shield 14. **RK 11868**¹

15. **RK 11-1910** Drain Fitting Kit Drain O-ring Kit **RK 11340**

Probe Port Rlug Kit 16. RK 20022

Additional Parts (not shown)


RK 19492 Marine Shut-off Valve Kit **RK 21069** Water Probe Kit Plastic Body Plug Kit RK 11-1679

RK 11-1404 Complete Seal Service Kit 19526 instaliation Instructions Base with 22x1.5 mm ports N/A

1For replacement only. The Coast Guard does not accept

'FH' units converted to 'MA' configurations.





How to Order

(The example below illustrates how the part numbers are constructed).

1000MA	М	10
Basic Model Use model 1003MA for 22x1.5 mm metric thread	Add M for metal bowl.	Add: 2 (for 2 micron) 10 (for 10 micron) 30 (for 30 micron)


Replacement Element (seals included)				
2020SM-OR	2 micron	Final		
2020TM-OR	10 micron	Secondary		
2020PM-OR	30 micron	Primary ¹		

¹ A secondary or final filter is required downstream.

All 2020 Series filters are 9.6" tall by 4.7" in diameter.

Not all configurations are available - contact Technical Support for more information.

Mounting Information





Replacement Parts

1000MA and 1003MA

Part Number Description

1. **RK 11888** T-handle Kit (includes o-ring)

2. RK 11-1933-04 Lid Kit (includes #3)

3. 11007 Lid Gasket4. Replacement Element (includes #3)

2020SMOR 2 Micron Element 2020TMOR 10 Micron Element 2020PMOR 30 Micron Element

5. **RK 11815-102** Turbine Body Bracket Kit6. **RK 11-1776-05** 1000MA Base (include # 9)

11-1835-01 1003MA Base (with 1/2"-14 BSPT ports)

RK 11021-02 Outer Cylinder Kit (include # 9)

7. **RK 11028B** Checkball and Seal Kit

RK 11026D Turbine/Centrifuge Kit (includes # 7, 8 & 9)

9. 11007 Bowl O-ring

10. **RK 11-1606-1** Clear Bowl Kit (includes # 9 & 13) **RK 11734** Metal Bowl Kit (includes #'s 9, 12 & 15)

Matal Bowl (1/4"NDT)

RK 11734-01 Metal Bowl (1/4"NPT)

(includes #'s 9, 12, 15 & probe port plug)

11. **RK 11037A** Bowl Ring Kit (includes #12)

12. **RK 11542** Capscrew Kit (4 screws) (1/4"-20 x 1")

13. **RK 11341** Bowl Drain Gasket Kit **RK 11340** Drain Fitting O-ring

14. **RK 11868**¹ Heat Deflector Kit (includes #'s 13-15)

15. **918-N4** Bowl Plug (1/4" NPT)

RK 11-1910 Bowl Drain Fitting Kit

Additional Parts (not shown)

RK 20022 Probe Port Plug Kit

RK 19492 Shut-off Drain Valve Kit

RK 21069² Water Probe Kit (MA Bowls)


RK 11-1679 Plastic Plug Kit

RK 11-1404 Complete Service Kit

19526 Installation Instructions

¹For replacement only. The Coast Guard does not accept 'FH' units converted to 'MA' configurations.

²For diesel service only. Must be used with a Water Detection Kit.





How to Order

(The example below illustrates how the part numbers are constructed).


731000MA	M	10
Basic Model	Add M for metal bowl	Specify: 2 (for 2 micron) 10 (for 10 micron) 30 (for 30 micron)

	Replacement Element (seals included)	
2020SM-OR	2 micron	Final
2020TM-OR	10 micron	Secondary
2020PM-OR	30 micron	Primary ¹

¹ A secondary or final filter is required downstream.

Not all configurations are available - contact Technical Support for more information.

Mounting Information





Replacement Parts

731000MA

Part Number Description

1. 1000MA Refer to model 1000MA

for a complete part breakdown.

2. 11-1629-01 Dual unit Bracket

11895-02 Clamp Bracket Assembly

3. 11923 Outlet Manifold

4. **11072** Elbow Fitting (Parker #2507-10-8)

5. **11892** Inlet Manifold

Additional Parts (not shown)

RK 19492 UL Listed Brass Marine Valve Kit

(use two for use with this unit)

19531 Installation Instructions

For water detection kits see the marine Accessories.











Installation Instructions

New filter installations must be filled with fuel and the fuel system must be adequately primed following the engine manufacturer's recommendations. Existing installation difficulties are usually associated with improper priming procedures or damage to the unit or fuel system. The result is either internal air suction or external fuel leakage. Diagnose with the following steps:

- 1. Check fuel tank level and verify fuel delivery valves are open.
- 2. Verify T-handle, bowl fasteners and fuel fittings are tight and bowl drain is closed.
- 3. If element is new, check potential restriction at fuel tank draw tube. An in-tank strainer may be plugged.
- 4. Review other troubleshooting instructions to uncover other solutions.

Correct external fuel leaks immediately! These conditions result in reduced engine performance such as: hard starting, stalling, reduced power and fire hazards.

Correct Application

It is very important that Turbine Series filter assemblies are not junder specified' for the application. The maximum fuel flow rating of the filter assembly must not be exceeded; doing so will reduce efficiency and de-gas (pull air from) the fuel.

Filter Elements

Replacement elements are available in 2, 10 and 30 micron ratings (nominal). Filtration needs are based on application, fuel quality, maintenance schedules and operating climates. A simple rule to remember is... the finer the filtration, the more frequent the filter change interval.

Always carry extra replacement elements with your equipment as one tankful of excessively contaminated fuel can plug an element quickly, When clogged to maximum capacity, elements will have a brown to black color or tar like contaminants may be present - this is normal. An appearance of a multi-colored slime (which may have a foul odor) is an indication of microbiological contamination. This condition must be treated immediately. Racor offers a wide variety of gasoline and diesel additives to prevent and treat these problems; see 'Additives' section of this catalog. Severe conditions must be corrected by a repair facility.

Never operate a filter assembly without the element in place.

The element safety valve on the fuel return tube will not expose the outlet hole if the element is removed. Instead, punch the emergency tab on the top of the element and leave in place.

Warning! Puncturing the emergency tab will bypass all filtration and send unfiltered fuel to your engine. Service the element as soon as possible to avoid harmful contaminants flowing downstream to the engine.

Water Sensors

This feature alerts the operator of a high-water condition. The bowl must be drained of water at the earliest convenience

A Racor water detection module is needed to work with the in-bowl sensor

The unit should activate when the water reaches the sensor tips (and when they measure below 47,000 or 100,000 ohms of resistance, depending on the detection module used). If not, the tips may be fouled with a coating. Remove the sensor and clean the tips with a cloth. Run a jumper wire between the tips with the ignition ON to test the system. Difficulties usually lie in the wire connections, power source, or an independent ground.





All Marine Turbine Series filters are 100% tested to ensure a leak-proof, quality product.

Apply Parker Super O-lube (part number RK31605) or equivalent to all seals at major attachment points to maintain integrity, seal elasticity, to fill small voids and provide protection from degradation.

Perform the following checks with the engine OFF (and applicable valves closed). For replacement parts, refer to the appropriate 'Replacement Parts' section of this catalog.

Damaged, worn, or dirty seals will allow air ingestion. Inspect and replace all seals as needed. Lube all seals with Parker Super O-lube. Clean sealing surfaces of dirt or debris every time element is replaced.

Hand tighten T-handle; do not use tools!

If element is changed or assembly drained for any reason, repriming assembly (filling with fuel) may be necessary. Fill to just above top of element before replacing lid.

Do not overtighten carriage bolt as this may distort cylinder roundness.

Do not overtighten self-tapping screws; this may strip the treads. After disassembly, start screws by hand prior to using tools. Specification: 55 to 65 in. lbs.

The hollow aluminum check-ball floats up against the seal when the fuel is stopped thus preventing fuel bleed-back. If your unit looses prime, inspect upstream hose connections first, otherwise, disassemble the unit and inspect the seal and ball.

Drain water before it reaches this level.

Air bubbles or fuel leakage appearing from drain may indicate that drain is closed completely or that seal has been clogged with contaminants. Tighten drain and inspect: If self-venting drain will not work when opened, it may be clogged. Cycle drain (open-close) or attach a hose and briefly apply air (<2-3/PSI with T-handle and lid removed) to disloge contaminants. Element should be replaced every 10,000 miles every 500 hours, every other oil change, annually or at first indication of power loss, whichever occurs first. Construction and agricultural equipment should change element every 300 hours.

SAE O-ring ports should have a smooth angled seat for sealing. Do not scratch this surface. Check O-ring for damage. Replace if necessary.

Heater feed-thru O-ring must not be damaged or swollen. Tighten snugly. Specification: 15 to 20 in. lbs.

Air bubbles appearing from turbine are an indication of an upstream leak between Racor inlet and fuel tank pick-up tube.

A water sensor plug is standard equipment on new assemblies. Water sensor kits are available as accessories; see the 'Accessories' section of this catalog. Tighten plug or water sensor snugly. Specification: 15 to 20 in. lbs.

Water sensors activate when water contacts the sensor tips. Air bubbles or fuel leakage appearing from sensor area may indicate that it is loose or O-ring is damaged. Tighten or diassemble and inspect.

Specification: 15 to 20 in. lbs.

